

iPhone Monitoring Software Operational Manual


Welcome to use iPhone monitoring software. This software can be searched from "ATVCLOUD". User just input "Auto id". This iPhone monitoring software can be applied on 4.3 version or above iPhone (it contains iPhone5) and iPad.

Operation and function of this monitoring software is introduced in below:

1. Register and login


This iPhone monitoring software is different with previous monitoring software. It is needed to be registered at first and then user can login and then manage iPhone or iPad. In this way, user don't need to remember many Device ID , it just need to remember register name to manage many devices.






The login page features a light blue background with a stylized cloud graphic. It contains two input fields: the first is labeled 'E-mail/Phone/Username' with a person icon, and the second is labeled 'Password' with a lock icon. Below these fields is a prominent blue 'Login' button. At the bottom, there are two smaller buttons: 'Demo' and 'Register', with the 'Register' button highlighted by a red rectangular border.

Login page




The register page has a blue header with a back arrow and the title 'Register'. It includes three input fields: the first contains the phone number '13153190505', and the next two are for a password, each represented by a series of dots. A blue 'Finish' button is positioned at the bottom of the form.

Register page




This screenshot shows the login page after a successful registration. The 'E-mail/Phone/Username' field is now populated with '13153190505', and the 'Password' field contains dots. The blue 'Login' button is highlighted with a red rectangular border. The 'Demo' and 'Register' buttons remain at the bottom.




The 'Device List' page features a blue header with a back arrow, the title 'Device List', and a plus icon. Below the header is a promotional banner for a 'NEW' feature: 'Alarm info sent to you immediately. No matter where you are, you can learn easily the abnormal at the first time.' The banner includes an image of a security camera. The main content area shows a large, faint icon of a person's head with a speech bubble, and the text 'No device Please add the device'. A blue 'Demo' button is located in the bottom right corner.

Registered user name and password are correct and login successfully.

2. Add Device and Connect


When login is successful, click the  at top right side of interface and input required

device's ID then input this device's user name and password to finish addition.




The screenshot shows a mobile application interface titled "Device List". At the top, there is a blue header bar with a back arrow on the left and a plus sign on the right. Below the header, the "Device ID" label is followed by a text input field containing the text "A361". Underneath the input field are two buttons: "Setting" and "Save". A numeric keypad is displayed at the bottom of the screen, featuring digits 0-9, symbols like "-", "/", ":", ";", "(", ")", "\$", "&", "@", and " ", as well as a "space" button and a "return" button.

Click Setting button to change network user name or password.



The image consists of two side-by-side screenshots of the "Device List" application. The left screenshot shows the "Device List" screen with the "Device ID" field filled with "A361". Below it, the "Username" field contains "abc" and the "Password" field is masked with three dots. There are "Back" and "Save" buttons at the bottom. A full QWERTY keyboard is visible at the very bottom. The right screenshot shows the same "Device List" screen, but with a "NEW" banner at the top that says "Alarm info sent to you immediately. No matter where you are, you can learn easily the abnormals at the first time." Below the banner is a "Searching device information Please wait..." dialog box with a loading spinner. At the bottom of the right screenshot, there is a message that says "No device Please add the device".


After input network user name and password and save them, then it starts to search device.




When search is successful, click the device and some channels will be displayed.

When device is added successfully, the software will automatically search this device's channel. It is not needed to input channel's numerical value by manual. The more channels are, the longer it will take time.


When addition is successful and click the channel, it will make connection.



Click the channel and it will make connection successfully.



If user want to watch other channels, it just need to slide images.



It also is optional to click back button  to disconnect the current

channel and then connect other channel.


3. Main Function

3.1 Audio monitoring

It can be used to monitor audio from host-end. The host-end should be connected with audio receiver and audio compression should be started too. At the same time audio function should be enabled at iPhone.


3.2 PTZ control

The iPhone can be used to control PTZ. The up, down, left or right direction can be adjusted. The zoom and focus can also be adjusted through iPhone.




3.3 Remote Playback

This monitoring software can be used to playback the host-end's video on iPhone. When there is video in host-end and it can be searched and played remotely by iPhone. Please note that there is no audio during playback. While snapshot or video recording also can be realized on iPhone during playback.



Click playback and it acquiescently retrieves intraday video at host-end.



Select one video file and start to play it.

3.4 Capture

This monitor software make iPhone snapshot image when real time video is playing or


the video is in playback station. Images will be stored at iPhone and it is easy to be managed by user.


3.5.Video

This software can make iPhone make video recording. Video files will be stored at iPhone and it is easy to be managed by user.


4. Other functions

There are two ways to open the other functions. It is located at bottom right side of main

interface. The icon is 




It can also be found at device list.



There are two important functions in this section. One is switch button of alarm and the other is switch button of scene picture.

Alarm: Switch on alarm button. When there is an alarm on one device, it will send alarm message to client-end. No matter the software is online or not, iPhone or iPad can receive this message.

Scene picture: Switch on scene picture button. After the device is connected successfully, each channel holds the last frame's image when it was connected last time. It will help user to refresh his memory and make selection. At the same time, when scene picture is switched on, it will be slow to use user name to login. So the scene picture function is advised to be switched off.




Scene picture function is on,


Scene picture function is off.

5. Demo

The iPhone monitoring software has Demo function. It makes user test remote connection's effect at any time. Click Demo at login interface.



Click Demo at login interface. Or Click Demo at bottom right side of main interface after login successfully.



There are two Demos. Click picture on map and it connects demo successfully.